



Body-Worn Camera Magnetic Mount User Guide

P/N: PMLN8221A



Used Device: Si200 Body-Worn Camera

Operational Safety Guidelines

Some Motorola Solutions' magnetic mount carry options incorporate strong neodymium magnets. If you are using a personal medical device as a pacemaker or a hearing aid, consult the manufacturer of your device to determine if it can be used in close proximity to magnets. Your physician may be able to assist you in obtaining this information.

Also be aware that magnets can damage other products including cell phones, computers, hard drives, and other electronic devices, as well as credit cards and magnetic media. Keep the magnetic mounts away from any mechanical device that can be affected by a magnetic field. Consult the manufacturer of your product to determine if your device or product can be used in close proximity to magnets

MN005552A01-A

Printed in China

Magnetic Uniform Mount Overview




Figure 1: Magnetic Mount Overview

Magnetic Uniform Mount

1. While the two magnetic plates are attached together, slide down the camera mounting plate into the groove on the back of camera until it clicks




Figure 2: Attaching Camera to the Magnetic Plate

Table 1: Magnetic Mount Parts Description

Callout	Description
1	Magnetic Mount
2	Backer Plate
3	Magnets Inside Backer Plate
4	Camera Mounting Plate
5	Sliding Track to Attach the Camera
6	Magnets Inside Camera Mounting Plate

Separate the Magnetic Plates

2. Twist and push the Camera Mounting Plate and the Backer Plate in opposite directions to separate them from each other.




Figure 3: Detaching the Magnetic Mount

Attaching Magnetic Uniform Mount

Position the Backer Plate beneath your garment with the Motorola Solutions logo facing the body and the magnets facing away from your body. Place the Camera Mounting Plate with the attached camera on the outside of the garment over the Backer Plate.





Figure 4: Attaching the Magnetic Mount

Wearing Positions

Note: Black dots indicate possible wearing positions



Polo Shirt



Coat/Jacket

Warranty and Service Support

Warranty

Motorola Solutions offers a standard one-year warranty. Contact your Motorola Solutions dealer for detailed information on the standard warranty.

Note: Warranty is voided if you replace any parts other than the replacement part listed.

Service and Support

Contact Motorola Solutions Customer Care at 1-800-422-4210 for ordering or any technical troubleshooting assistance.



Uniform



Tactile Vest